20mm

Back side of sand papeı

- 1. Copy the pattern (PART A) to any sand paper you like
- 2. Copy the pattern (PART B) to a strong tape or any material strong enough for holding both sides of sand paper
- 3. Cut out the shapes (Both PART A and PART B)
- 4. Glue PART A with area indicated in the pattern, Glue PART B by instruction (may not need to glue if you use very strong tape with strong adhesiveness)
- 5. Overlay PART A glued area with PART B and form a loop
- 6. Wait until the glue is dried and strong
- 7. Install it on your sand block =) (modify the length based on your sand paper)

Feel free to send DM on Instagram or email us if you have anything unclear. Instagram: amyroke email: info@amyroke.com

PARTA

20mm